


# C5M-5601A

5.6" Color TFT LCD  
Stand-alone type Monitor



## INSTRUCTION MANUAL

### ■ IMAGE REVERSE

When the reverse diagram show on screen , press  $\triangle$  or  $\nabla$  on the monitor or ADJUST key  $\triangle$ / $\nabla$  on the remote controller to adjust vertical / horizontal reverse function On/Off.

**V $\triangle$  REV.V $\nabla$ H**  
OFF OFF

### ■ DIMMER FUNCTION

When the Dimmer diagram show on the screen , Press  $\triangle$  or  $\nabla$  on the monitor or ADJUST key  $\triangle$ / $\nabla$  on the remote controller to select 100% or 50% dimmer function.

**DIMMER**  
100%


### ■ DISPLAY MODE SELECT

When the MODE diagram show on the screen ,Press  $\triangle$  or  $\nabla$  on the monitor directly or ADJUST key  $\triangle$ / $\nabla$  on the remote controller to select FULL/NORMAL/ZOOM 1/ZOOM 2/ZOOM 3/WIDE display mode.


**MODE**  
FULL

## ATTACHMENTS

- CABLE : "P/N : 55-1000-0306"  
Length : 100 cm



## APPEARANCE




1. MENU
2. DOWN
3. UP
4. POWER SWITCH
5. REMOTE CONTROL SENSOR

## FUNCTIONS

### ■ VEDIO INFORMATION

When press  $\odot$  power button to power on , the video information will be show on Left-up conner of screen.



### ■ VEDIO SELECTION


Press  $\triangle$  or  $\nabla$  on the monitor directly or ADJUST key  $\triangle$ / $\nabla$  on the remote controller to select video channel.



### ■ BRACKET : P/N : ST-031 \*



## DIMENSIONS




## SYSTEM ADJUSTMENT

To press  $\diamond$  on the monitor or MENU key  $\text{Ⓜ}$  on the remote controller, the screen will appear diagrams of adjustment items in turn(BRIGHT/COLOR/CONTRAST/TINT/REV/DIMMER/MODE) . Press the button  $\diamond$  or  $\text{Ⓜ}$  again until the item which you want to adjust showed on screen and then press  $\triangle$  /  $\nabla$  on the monitor or ADJUST key  $\triangle$  /  $\nabla$  on the remote controller to select to adjust the monitor system .

### ■ PICTURE ADJUSTMENT ITEMS :BRIGHT/COLOR/CONTRAST/TINT

When the BRIGHT/COLOR/CONTRAST/TINT adjustment bar show on the screen , Press  $\triangle$  or  $\nabla$  on the monitor or ADJUST key  $\triangle$  /  $\nabla$  on the remote controller to adjust quality of picture.



## SPECIFICATIONS

DISPLAY RESOLUTION	5.6" Color TFT LCD (16:9) 1440(H) x 234(V) Total 336,960 dots
BACK LIGHT	CCFL
LAMP LIFE	30,000 hr. (at Tamb =25 °C)
INPUT SIGNAL	NTSC & PAL (auto-switch)
POWER SOURCE	DC 12V $\pm$ 15% (ripple 0.5 Vp-p max.)
RANGE OF OPERATING VOLTAGE	DC 12 $\pm$ 15%
POWER CONSUMPTION	9W max.
CONTRAST RATIO	350 TYP.
BRIGHTNESS	350 nit TYP.
VIEWING ANGLE	TOP 35 deg. BOTTOM 15 deg. LEFT/RIGHT 50 deg.
OPERATING TEMPERATURE	-30 °C ~ 80 °C (240hr)
STORAGE TEMPERATURE	-40 °C ~ 85 °C (240hr)
OPERATING HUMIDITY	85% RH max.
STORAGE HUMIDITY	85% RH max.
OVERALL DIMENSIONS	152.0(W) x 103.6(H) x 24.0(D)
WEIGHT	TBD

## CAUTION

1. Don't expose to direct sunlight.  
( refer to specification)
2. Don't expose temperature extremes.  
( refer to specification)
3. Avoid dropping and strong impact.
4. Avoid wet and dust.
5. Never attempt to take apart and maintain by yourself.